



NOTES:  
1. THIS PRODUCT IS PROTECTED BY A MANUAL RESET CIRCUIT BREAKER LOCATED NEAR THE STARTER. EXCESSIVE CURRENT WILL CAUSE THE BREAKER TO TRIP AND THE ENGINE WILL SHUT DOWN. THE BUILDER/OWNER MUST BE SURE THAT THE INSTRUMENT PANEL, WIRING, AND ENGINE ARE INSTALLED TO PREVENT CONTACT BETWEEN ELECTRICAL DEVICES AND SEAWATER.  
2. AN ON-OFF SWITCH SHOULD BE INSTALLED BETWEEN THE BATTERY AND STARTER TO DISCONNECT THE BATTERY IN AN EMERGENCY AND WHEN LEAVING THE BOAT. A SWITCH WITH A CONTINUOUS RATING OF 175 AMPS. AT 12 VDC WILL SERVE THIS FUNCTION. THIS SWITCH SHOULD NOT BE USED TO MAKE OR BREAK THE CIRCUIT.

TOLERANCES		WESTERBEKE CORPORATION	
UNLESS OTHERWISE NOTED		AVON MA. 02322	
INCHES	MILLIMETERS	TITLE	
.0015	.05	WIRING DIAGRAM	
.0025	.10	TA ONE	
.0050	.20	DATE	
.0100	.40	DRAWN BY	
.0150	.60	CHECKED BY	
.0200	.80	APPROVED BY	
DIMENSIONS		DATE	
INCHES		REV.	
MILLIMETERS		E 44542	
OTHER APPLICABLE		REV. 1 OF 1	